

Before You Begin...

Read all instructions, diagrams and illustrations before installing your new Eagle Eye Lights product. Check owners manual for installation and use of auxiliary lights. Mounting location must not affect normal operation of vehicle. Before drilling make sure no components can be damaged behind mounting surface. Check local and state laws regarding the use of auxiliary lighting. Some states require auxiliary lights to be used only in conjunction with headlights.

Caution

Check for airbags sensor locations in your vehicle's owners manual. If sensors are located in or on front bumper or spoiler **DO NOT DRILL MOUNTING HOLES AT THOSE LOCATIONS**. Do not use higher rating fuses or bulbs than specified. If you do not have knowledge of 12V electrical systems and you are unsure about any aspect of these installation check with qualified automotive mechanic or technician. Make sure when installing your Eagle Eye Lights that all your wiring, cable and wiring components are not installed or placed where it might have contact with any moving parts or hot engine surfaces.

Lamp & Bracket Installation:

1. Select desired location for your Eagle Eye Lights.
2. Install U-bracket by drilling 7/32" mounting holes surface, using gasket and self-tapping screws.
3. Reinstall lamps on bracket, follow wiring installation.

A. Lights wiring harness:

1. Disconnect negative (-) cable from battery.
2. Connect wires to lamps as shown in wiring diagram.

B. Relay:

1. Install relay in dry location inside engine compartment. Wiring should reach from/to relay, battery, lamps and switch.
2. Drill 1/16" hole for relay mounting screw. Install relay.
3. Connect wires to relay (refer to wiring diagram).
4. Run wiring from/to relay through engine compartment in-wall and into passenger compartment.

NOTE: Do not inert wires through tire-wall openings which have sharp edges and moving components, could cause short circuit.